



DIP Switch Settings for the Sportster Modem

- 1 UP DATA TERMINAL READY NORMAL
 DOWN DTR OVERRIDE

- 2 UP VERBAL RESULT CODES
 DOWN NUMERIC RESULT CODES

- 3 UP SUPPRESS RESULT CODES
 DOWN DISPLAY RESULT CODES

- 4 UP ECHO OFF LINE COMMANDS
 DOWN NO ECHO, OFFLINE COMMANDS

- 5 UP AUTO ANSWER ON RING
 DOWN SUPPRESS AUTO ANSWER

- 6 UP CARRIER DETECT NORMAL
 DOWN CARRIER DETECT OVERRIDE

- 7 UP LOAD NVRAM DEFAULTS
 DOWN LOAD FACTORY DEFAULTS

- 8 UP DUMB MODE
 DOWN SMART MODE

FACTORY DEFAULT SETTINGS FOR THE SPORTSTER MODEM IS 3,5 AND 8 DOWN, ALL THE REST UP.